


Menu Board Wall Mount



INSTALLATION MANUAL

MTLWMA2

VESA Compatible
200x200/300x300/400x200
400x400/600x400

55"
MAX

rated
50kgx2/110lbsx2

 **Read the entire instruction manual before you start installation and assembly. If you have any questions regarding any of the instructions or warnings, please contact your local distributor for assistance.**


CAUTION

- Use with products heavier than the rated weights indicated may result in instability causing possible injury.
- Please closely follow the assembly instructions. Improper installation may result in damage or serious personal injury.
- Safety gear and proper tools must be used. This product should only be installed by professionals.
- This product is designed to be installed on solid concrete walls or masonry walls.
- Make sure that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.
- Use the mounting screws provided and **DO NOT OVER TIGHTEN** mounting screws.
- This product contains small items that could be a choking hazard if swallowed. Keep these items away from children.
- This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.


Recommended for Installation



Component Checklist



mounting rail (x1)
A



wall plate (x2)
B



TV bracket (x4)
C



end cap (x2)
D



M8x12 (x8)
E



sliding nut (x10)
F




M8x10 (x2)
G



D8 washer (x2)
H



cable clip (x4)
I



locking piece (x4)
J




4mm Allen Key (x1)
K




5mm Allen Key (x1)
L

IMPORTANT: Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, contact your place of purchase for a replacement.


Package M x2




M6x14 (x4)
M-A



M8x16 (x4)
M-B



M6x30 (x4)
M-C




M8x35 (x4)
M-D



D8 (x4)
M-E




Ø15xØ8x5 (x4)
M-F




Ø15xØ8x15 (x4)
M-G

Package W x2



ST6.3x55 (x4)
W-A




concrete anchors (x4)
W-B




D6 washers (x4)
W-C


1. Attach Wall Plate to the Mounting Rail



2. Install the End Cap




3. Attach Mounting Rail to Solid Brick or Concrete




W-A		W-B	
W-C			

4. Tilt Adjustment




20° is the natural angle and the safety pin is unnecessary.


5. Attach TV Bracket





Attach TV Bracket to Screen






6. Hang the Screen



7. Level Adjustment



8. Secure with Padlock



Note: Padlock is not included.

Maintenance

- Check that the bracket is secure and safe to use at regular intervals(at least every three months).
- Please contact your distributor if you have any questions.