


Menu Board Wall Mount



INSTALLATION MANUAL

MTLWMA3

VESA Compatible
200x200/300x300/400x200
400x400/600x400

50"
MAX

rated
50kgx3/110lbsx3

 **Read the entire instruction manual before you start installation and assembly. If you have any questions regarding any of the instructions or warnings, please contact your local distributor for assistance.**


CAUTION

- Use with products heavier than the rated weights indicated may result in instability causing possible injury.
- Please closely follow the assembly instructions. Improper installation may result in damage or serious personal injury.
- Safety gear and proper tools must be used. This product should only be installed by professionals.
- This product is designed to be installed on solid concrete walls or masonry walls.
- Make sure that the supporting surface will safely support the combined weight of the equipment and all attached hardware and components.
- Use the mounting screws provided and DO NOT OVER TIGHTEN mounting screws.
- This product contains small items that could be a choking hazard if swallowed. Keep these items away from children.
- This product is intended for indoor use only. Using this product outdoors could lead to product failure and personal injury.


Recommended for Installation



Component Checklist



mounting rail (x2)
A



wall plate (x3)
B



TV bracket (x6)
C



end cap (x2)
D



M8x12 (x12)
E



sliding nut (x14)
F



M8x10 (x2)
G



D8 washer (x2)
H



cable clip (x6)
I



3mm Allen Key (x1)
J



4mm Allen Key (x1)
K



5mm Allen Key (x1)
L



locking piece (x6)
M




connecting bar (x3)
N




M6 (x12)
O

IMPORTANT: Ensure that you have received all parts according to the component checklist prior to installation. If any parts are missing or faulty, contact your place of purchase for a replacement.


Package M x3




M6x14 (x4)
M-A



M8x16 (x4)
M-B



M6x30 (x4)
M-C



M8x35 (x4)
M-D



D8 (x4)
M-E




Ø15xØ8x5 (x4)
M-F




Ø15xØ8x15 (x4)
M-G

Package W x3



ST6.3x55 (x4)
W-A




concrete anchors (x4)
W-B




D6 washers (x4)
W-C


1. Extend the Mounting Rail




2. Attach Wall Plate to the Mounting Rail





3. Install the End Cap




4. Attach Mounting Rail to Solid Brick or Concrete






5. Tilt Adjustment







20° is the natural angle and the safety pin is unnecessary.



6. Attach TV Bracket






Attach TV Bracket to Screen





7. Hang the Screen









8. Level Adjustment



9. Secure with Padlock



Note: Leave at least 1mm gap between screens.



Note: Padlock is not included.

Maintenance

- Check that the bracket is secure and safe to use at regular intervals(at least every three months).
- Please contact your distributor if you have any questions.