



ASSEMBLY INSTRUCTIONS




Max load: 8kgs During Moving


► SCREW PACKAGE





► PARTS INCLUDED





► INSTALLATION





3




4



5



6



Warning: When the ground is uneven and you feel the table is shaking, please adjust the wheels to make it flat.